Building in the Scan 5004-S against a flammable wall Installation with an insulated flue pipe Ceiling - Insulated length Cavities are not to be filled out with insulation material! WARNING! Keep the convection air intakes free from blokage



Flammable material

All distances are in mm.

All distances are minimum distances

These distances apply for an insulated flue pipe all the way down to the stove $% \left\{ 1,2,\ldots ,n\right\} =0$

Floor

^{*} Distance to glass
** Distance to flammable ceiling